

KWIK-SITE



27367 MICHIGAN AVENUE / INKSTER, MICHIGAN / 48141

KWIK-SITE ◦ KWIK-MOUNT ◦ KWIK-MOUNT/94

INSTALLATION INSTRUCTIONS

for factory-drilled and tapped rifles

1. Check to be certain you have the correct Kwik-Site mount designed for your rifle.
2. Place rifle in a padded vise making sure it is horizontally and vertically level.
3. Thoroughly clean receiver surface of oil or dirt. Carefully remove dummy screws.
4. Attach the front and rear mount bases to the receiver using the screws* included.
5. Place scope on the mount rings and check for clearance and eye relief adjustment. Most front or rear bases can be reversed to achieve the proper scope positioning.
6. Firmly tighten base screws using shellac or "Lok-Tite" on threads for a permanent set. Lightly tapping on the screwdriver at final turn will help ensure firm set.
7. Reposition scope in the mount base rings and install upper rings using the screws provided. Evenly tighten the upper ring screws leaving clamping pressure on tube sufficiently free for final adjustments.
8. Remove rifle from vise and assume normal shooting stance. Move scope to front or rear for critical eye relief adjustment.
9. Place rifle in vise for checking reticle alignment. Turn scope tube as necessary for correct alignment of the crosshairs. Tighten the ring screws by crisscrossing evenly back and forth taking care not to overtighten. Recheck reticle alignment.
10. Scope can now be rough-sighted in before shooting by boresighting down the barrel at a minimum recommended target distance of 25', or use of an optical bore sight.